

# UNION ELECTRIC COMPANY GAS SERVICE

Applying to MISSOURI SERVICE AREA

## VI. Customer's Installation

### A. Installation Standards

Customer's piping and gas burning equipment will be installed, operated and maintained by customer in conformity with applicable engineering standards, with the requirements of constituted authorities and with these Rules and Regulations. American National Standard - National Fuel Gas Code (latest edition) shall govern where no other code exists or where a local code is less restrictive than the National Fuel Gas Code.

### B. Customer Responsibility

Customer will be totally responsible for the design, operation and continuing condition of customer's installation. Customer will also be liable for any loss, damage or injury caused by leakage, escape, or loss of gas on customer's side of the point of delivery.

### C. Unsafe Conditions

Gas will be turned on only by Company. Company will refuse to turn on gas if it is known or suspected, or may without prior notice turn off gas if it is known or suspected, in Company's judgment, that customer's piping or appliances are in an unsafe condition, and service will not be turned on until such conditions are remedied.

DATE OF ISSUE December 2, 1988DATE EFFECTIVE January 1, 1989ISSUED BY William E. Cornelius

Chairman

St. Louis, Missouri

Name of Officer

Title

Address